

70.00 mm

85.00 mm

**TENERGY**

Part number: 01141

# 9V Battery Charger

For Ni-MH/Ni-CD rechargeable batteries

USER MANUAL



User Manual

## IMPORTANT SAFETY INSTRUCTIONS:

1. SAVE THESE INSTRUCTIONS & CAREFULLY FOLLOW THEM, TO REDUCE THE RISK DANGER OF FIRE OR ELECTRIC SHOCK.
2. This charger is intended for Ni-MH/NiCD rechargeable batteries only. Attempting to charge non-rechargeable batteries may cause personal injury and damage to the charger.
3. Do not expose charger to water or moisture. For indoor usage only.
4. Remove from power when not in use.
5. Do not operate the charger if it has been subjected to shock or damage.
6. Do not disassemble the charger. Incorrect reassembly may result in a risk of electric shock or fire.
7. Unplug the charger from USB port before attempting any maintenance or cleaning. Use damp cloth to clean the surface, do not immerse into water.
8. Before scrapping your charger, remove batteries from the unit and recycle or dispose the batteries safely.
9. This appliance is not recommended for children under 8 years old or persons with reduced physical, sensory, or mental capabilities. Adult supervision is recommended.
10. Do not let children play with the appliance, it is not a toy.
11. Cleaning and user maintenance shall not be made by children without adult supervision.

User Manual

## Features

- DC 5V 1A USB input.
- Recharges 1 or 2 pieces of 9V NiMH / 9V NiCD batteries at a time.
- LED display for charging status.
- Negative Delta V cut-off, timers cut-off, reverse polarity protection.

## Charging Instruction

1. Insert 1 or 2 pieces of rechargeable 9V size NiMH / NiCD battery into the battery compartment. Make current contact for polarity (+ and -) according to the sign in the battery compartment.
2. Connect the charger with supplied USB cable into a standard 5V 1A USB port (not included). The LED will indicate charging status.
3. After charging, remove battery from charger, disconnect charger from power.

User Manual

## LED Indicator

Charger initialization (Connected to power)	Red and then Green
Standby	Solid Green
Charging	Solid Red
Charging Completed	Solid Green
Bad Cell Detected	Red Flashing
Charging Error / Abnormal Input	Red Flashing (Both bays)

## Thank you for your purchase

Please contact us directly if you have any questions or need any support!



510-979-9969



service@tenergy.com